

Turtle Racing 5B Front HD Shock Mount TUR0006

Kit includes:

1pcs TR HD Shock Mount

2pcs M4x35 FlatHeads

2pcs M4x30 ButtonHeads

2pcs M4 Lock nuts



This product only fits 5B

1. Remove 2 screws on shock tower and 2 screws holding top of shocks.



2. Install 2pcs M4x35 Flathead in shock tower. These screws are longer than stock and will go through the plastic shock tower. Either drill through shock tower with a 1/8" (3mm) drill or just drive the screw through the plastic. After you drive screw through, back it out and trim plastic flat with a knife or Dremel, run screws back in and install M4 locknuts.



3. Insert shocks into mount, install and tighten M4x30 ButtonHead

