## **Turtle Racing Rear HD Shock Mount TUR0005**

Kit Includes:

1pc Rear HD Mount
2pcs M4x25 SocketHead
2pcs M4x35 FlatHead
2pcs M4x25 ButtonHead

2pcs M4 LockNut



Install is the same for all Baja models and the Rear HD fits all Baja models, you will just need to work around the different cages as needed.

**1.** Remove 4 screws from stock shock mount and 2 screws from shocks. Remove shocks from tower and remove stock shock mount.



2.Install mount using 2pcs-M4x35 flatheads in the lower holes and 2pcs-M4x25 socketheads in the top holes. The top screws are longer than stock and will go through the stock plastic shock towers. You have 2 options- drill through the plastic with 1/8" (3mm) drill or just drive the screws right through.





## 3.Install shock into mount and install M4x25 buttonheads, install M4 nut on backside of M4x25 buttonheads





## **Install option**

Back the 2pcs-M4x25 socketheads in top holes out and use a utility knife or Dremel the cut the plastic, cut a notch to clear a nut and install M4 nut for added strength





